

Healthy Advice Networks[©]

WAITING ROOM NETWORK

Avocent Wireless KVM Installation Instructions

Longview Model

SARCOM

10300 ALLIANCE ROAD
SUITE 300
CINCINNATI, OH 45242

AVOCENT WIRELESS LONGVIEW 2.0

INSTALLATION INSTRUCTIONS

The Longview transmitter and receiver pair comes with the following:

- 1 – transmitter (has molded tail with (keyboard, video and mouse) KVM connectors.
- 1 – receiver
- 2 – power supplies
- 1 – Audio cable (for receiver)

Note: Before making any connections, all source and remote equipment must be “OFF” so that the wireless devices are correctly identified during system start up or re-boot.

Wireless KVM Setup Instructions:

1. Connect transmitter KVM (tail connectors) to server / PC (source) KVM connections.
2. Connect receiver KVM components on the remote PC/Laptop/Cart solution.
3. Power up both transmitter and receiver by plugging in the AC/DC adapters.

You will now have a duplicate screen at the source and the remote location.

Configuring the internal settings:

The Longview comes with a configuration menu within the transmitter and receiver (independent of the sources).

To access the menu, you must use the receiver mouse or keyboard.

To access the menu via mouse, perform the following mouse clicks (right, right, left).

A menu screen will pop up.

MAIN tab for KVM settings:

Click the “RUN AUTO SETUP”

Set the MODE for COMPUTER by clicking the CHANGE button.

ADVANCED tab settings:

Adjust settings to preferences.

NOTE: In order to save setting in the instance of a power failure or interruption, the SET AUTO “ON” mode must be set. This will ensure your custom settings will remain upon power loss.

If this mode is set for OFF, then the unit will default to the factory settings upon power up, requiring the menu to be accessed and all custom parameters to be adjusted once again.

To save all settings and exit menu, the FINISH button must be clicked. This will re-boot and update the transmitter and receiver pair.

Wireless (DVD) MODE Setup Instructions (Streaming Video or Digital Signage Broadcasting)

NOTE: To configure the Longview pair for DVD or streaming media/video:

All that is required is the video and audio cables connected at the source and remote projector/plasma/LCD/CRT.

To access the menu, you must use the receiver mouse or keyboard.

To access the menu via mouse, perform the following mouse clicks (right, right, left).

A menu screen will pop up.

Click the “RUN AUTO SETUP”
Set the MODE for DVD by clicking the CHANGE button.

Go to ADVANCED tab to make adjustments.
Save settings and exit menu by confirming the SET AUTO “ON” is set, and clicking the FINISH button.
Units will re-boot with custom settings.
(Contact the Help Desk with any questions – 1-866-665-0364).